

**CIRCUIT SYSTEMS - SPARES PRODUCT LIST**

ITEM DESCRIPTION	ITEM DESCRIPTION	ITEM DESCRIPTION	ITEM DESCRIPTION	ITEM DESCRIPTION
<b>EX-1000</b>	<b>FX-1170</b>	<b>TVSE QX SERIES</b>	<b>EX/LQ/HQ-1050/1040</b>	<b>FX-1050</b>
RIBBON MASK	RIBBON MASK	RIBBON MASK	RIBBON MASK	BUSH
R D G A	KNOB	KNOB	KNOB	PFR / PLATEN GEAR
KNOB	BUSH	BUSH	BUSH	KNOB
BUSH	CARRIAGE UNIT	CARRIAGE UNIT	CARRIAGE UNIT	HEAD CABLE
HEAD CABLE	HEAD CABLE	HEAD CABLE	HEAD CABLE - 9 PIN	R D G A
PLATEN GEAR	HOME P. SENSOR	R D G A	R D G A	PULLY
P F R GEAR	R D G A (GEARS)	PULLY - LHS	PULLY	RIBBON MASK
CARRIAGE WIRE	R D G A COMPLET	TIMING BELT	TIMING BELT	<b>LX-300</b>
R D G A WIRE	FRICTION LEVER	P F R GEAR	PFR / PLATEN GEAR	KNOB
PULLY - LHS	TIMING BELT	CR MOUNTING "U"	SPROCKET (Each)	BUSH
PULLY - RHS	PFR / PLATEN GEAR	SPROCKET (Each)	HEAD CABLE - 24 PIN	PFR / PLATEN GEAR
FRICTION LEVER	INTERMETTENT GEAR	<b>FX-1000</b>	PULLY REPAIR KIT	HEAD CABLE
CONTROL PANLE CABLE	<b>MSP SERIES</b>	BUSH	HOME P. SENSOR	R D G A
<b>LX-800</b>	RIBBON MASK	KNOB	PAPER E. SENSOR	RIBBON MASK
RIBBON MASK	KNOB	P F R GEAR	RIBBON MASK HOLDER	TIMING BELT
KNOB	BUSH	HEAD CABLE	<b>LQ-5400/2090/2050/5235</b>	PULLY LHS W/O.
BUSH	PFR / PLATEN GEAR	R D G A COMPLET	CARRIAGE - LQ-5400	PULLY LHS BEARING
SPROCKET (Each)	TRACTOR IDEAL GEAR	<b>DFX-8000/5000</b>	CARRIAGE - EX-5400	PULLY RHS
HEAD CABLE	LHS FRAME MAIN	Sprocket Front LHS	CARRIAGE - EX-2050	PINCH ROLLER
FRICTION LEVER	SPROCKET (Each)	Sprocket Front RHS	CARRIAGE - DSI-5235	CARRIAGE UNIT

PLATEN GEAR	SPROCKET LOCK	Sprocket Rear LHS	HEAD CABLE EX-5400	HEAD GAPE LEVER
P F R GEAR	R D G A WITH PLATE	Sprocket Rear RHS	<b>L &amp; T PARAGON - 36</b>	FRICTION LEVER
TIMING BELT	CARRIAGE - MSP 2XX	RIBBON MASK	HEAD CABLE	TRACTOR FRAME
PULLY - LHS / RHS	CARRIAGE - MSP 3XX	CARRIAGE ASS.8000	KNOB	SIDE FRAME - LHS
R D G A	CONTROL PANEL	Mask with Holder 8000	RIBBON MASK	SIDE FRAME - RHS
CARRIAGE UNIT	PULLY - LHS	<b>DFX-8500/5000plus</b>	P F R GEAR	TRACTOR GEAR
BASIC FRAME	PULLY - RHS	Sprocket Front LHS	CARRIAGE PIECE	ON / OFF SWITCH
ON / OFF SWITCH	PULLY LOCK LHS - Y	Sprocket Front RHS	R D G A	HOME P. SENSOR
PULLY BUSH	TIMING BELT	Sprocket Rear LHS	C I P ( Cartridge Holder )	PAPER E. SENSOR
R D G A COVER	HEAD CABLE MSP-345	Sprocket Rear RHS	SPROCKET LOCK	SPROCKET (Each)
PLATEN / C R LOCK	CR MOUNTING "U"	Mask with Holder 8500	PF MOTOR BRAS PULLY	<b>LQ-300</b>
OIL PAD	<b>NOVA-130 / LSP-100</b>	<b>PANASONIC KXP</b>	Head Mounting Block	KNOB
<b>LX-700/SX/DX/800DX</b>	KNOB	RIBBON MASK	BAIL LEVER LATCH	BUSH
R D G A WITH BELT	BUSH	CARRIAGE -1150/1121	HEAD CABLE GUIDE	PFR / PLATEN GEAR
KNOB	CARRIAGE UNIT	CARRIAGE -3696/3626	<b>LX-1050</b>	HEAD CABLE
RIBBON MASK	TIMING BELT	R D G A - 3696 / 3626	BUSH / RIBBON MASK	R D G A
FRICTION LEVER	PULLY - LHS / RHS	FRICTION LEVER ALL	PFR / PLATEN GEAR	RIBBON MASK
BUSH	<b>TVSE PROTON</b>	P F R GEAR ALL	KNOB	PULLY LHS BEARING
CARRIAGE - LX-700SX	CARRIAGE UNIT	HEAD CABLE - 3696	HEAD CABLE	CARRIAGE UNIT
CARRIAGE - LX-800DX	RIBBON MASK	HEAD CABLE - 1150	R D G A	SIDE FRAME - LHS
PULLY - LHS / RHS	TIMING BELT	PANEL CABLE - 3696	PULLY WITH BEARING	SIDE FRAME - RHS
SPROCKET (Each)	SPROCKET (Each)	PULLY - LHS - 3696	CARRIAGE UNIT	HEAD GAPE LEVER
PFR / PLATEN GEAR	PFR / PLATEN GEAR	PULLY - RHS - 3696	TIMING BELT	FRICTION LEVER